


EXIT WARNING

visually and acoustically warns the occupants if opening the door could result in a collision




SIDE ASSIST

monitors up to 70 m behind the vehicle



LANE ASSIST

now also keeps the vehicle in lanes marked out with yellow lines



TURN ASSIST

monitors oncoming vehicles when the driver wishes to turn left

