

EdelweissCompounding – The efficient approach to produce high-quality Compounds from plastic waste

Plastics Recycling Show Amsterdam 2017

Carl P. Pöpel; Head of Product Management Twin-screw Extrusion

PRS 2017



Agenda



KraussMaffei Group and KraussMaffei Berstorff



KMB Compounding



Recycling and EdelweissCompounding



Conclusion and Challenges

KraussMaffei Group and KraussMaffei Berstorff

KM - World market leader in machinery for plastics processing

NETSTAL

KraussMaffei

KraussMaffei
Berstorff



IMM
Injection Moulding Machinery
3 series
(clamping force: 50 – 800 t)

IMM
Injection Moulding
Machinery
4 series
(clamping force: 50 - 4000t)

RPM
Reaction Process Machinery
(polyurethane resins)

EXT
Extruders and Extrusion Systems
for processing
plastics and rubber

Agenda



KraussMaffei Group and KraussMaffei Berstorff



KMB Compounding



Recycling and EdelweissCompounding



Conclusion and Challenges

KMB Compounding

Definition

Compounding is the finishing process of Plastics through the incorporation of Additives in a melt viscous phase to create specific and optimized properties.

Process steps:

- Feeding
- Conveying / Transport
- Melting / Plastification
- Mixing (dispersive / distributive)
- Degassing
- Pressure build-up



KMB Compounding

Polymer spectrum

Standard Thermoplastics

- Low-density polyethylene (LDPE)
- Linear low-density polyethylene (LLDPE)
- High-density polyethylene (HDPE)
- Polypropylene (PP)
- Polystyrene (PS)
- Polyvinylchloride (PVC)
- Polyethyleneterephthalate (PET)

Engineering Plastics

- Styrene Acrylonitrile (SAN)
- Acrylonitrile-Butadiene-Styrene (ABS)
- Polyamide (PA 6, PA6.6, PA 12)
- Polybutyleneterephthalate (PBT)
- Polycarbonate (PC)
- Polymethyl methacrylate (PMMA)
- Polyoxymethylene (POM)

High-Performance Polymers

- Polyetheretherketone (PEEK)
- Polyphenylenoxide (PPO)
- Polysulfone (PSU)
- Fluoropolymers
- Polyimide (PI)
- Liquid crystal polymers (LCP)

Other Materials

- Thermoplastic elastomers (TPE, -S, -V, -U)
- Elastomers, e.g. SBR, EPDM, silicon rubber
- Thermosets, curable moulding compounds
- Flooring compounds
- Powder coatings, photocopy powders
- Ceramics and catalyst compounds
- Pharmaceuticals and foodstuffs

KMB Compounding

Additives spectrum

Reinforcements (abrasive)

- Glass Fibres
- Graphite Fibres
- Carbon Fibres
- Boron Fibres
- Whiskers
- Basal Fibres
- Titanium Fibres
- Synthetic Fibres
- Glass Beads
- Polymeric Hollow Beads

Fillers (abrasive)

- Calciumcarbonate
- Kaolin
- Wood Flour
- Wollastonite
- Barium Sulphate
- Silica
- Carbon Black
- Mica
- Talcum
- Metallic oxide/ metallic powder

Reactive Additives (abrasive+corrosive)

- Antioxidants
- Heat / UV Stabilizers
- Plasticizer
- Process Aids
- **Color Pigments**
- Static Inhibitors
- Microbicidal Additives
- Blowing Agents
- Primer
- Peroxide / Silane
- Flame Retardants (halogenes & halogene-free)
- Acids


KMB Compounding

ZE Series Extrusion portfolio



Lab Extruders:
ZE 25 A/R UTXi
ZE 28 BluePower

5 – 100 kg/h



High Performance
Compounding-Extruders:
ZE 42 - 80 BluePower

500 – 5.000 kg/h



Large Extruders:
ZE 90 – 180 A/R Uti


2 – 12 t/h



Standard Extruders:
ZE 52 - 77 BASIC /
Performance

300 – 3.000 kg/h

KMB Compounding Scope of Supply



Agenda



KraussMaffei Group and KraussMaffei Berstorff



KMB Compounding




Recycling and EdelweissCompounding



Conclusion and Challenges


Recycling and EdelweissCompounding

KMB Overview




Recycling and Edelweiss Compounding

KMB Overview




Recycling and EdelweissCompounding

KMB Overview



Recycling and EdelweissCompounding


Recycling with Twin-screw Extruder



Recycling and Edelweiss Compounding


Recycling with Twin-screw Extruder

Process example: Recycling of HDPE bottle
Regrind plus 2% Additives / Peroxide / CMB




Recycling and EdelweissCompounding

EdelweissCompounding with Single-screw + Twin-screw Extruder




Recycling and EdelweissCompounding

EdelweissCompounding with Single-screw + Twin-screw Extruder




Recycling and EdelweissCompounding

EdelweissCompounding with Single-screw + Twin-screw Extruder




Recycling and EdelweissCompounding

EdelweissCompounding with Twin-screw + Twin-screw Extruder



Recycling and EdelweissCompounding

EdelweissCompounding with Twin-screw + Twin-screw Extruder



Process example: 100 % PE or PP DSD-Recyclate with mineral filler (CaCO₃, Talc, TiO₂)
Output 1st stage: 3.000 kg/h; Output 2nd stage: 5.000 kg/h

Recycling and EdelweissCompounding

Up- and Downstream equipment - Filtration



Continuous Rotary drum
Filter; Ettliger design;
ERF 250



Continuous Rotary Drum
Filter; Nordson design,
HiCon R-Type 250



Continuous Rotary Disc
Filter; Erema design;
Laserfilter



Continuous Rotary Disc
Filter; MAS design; CDF
500D


Recycling and EdelweissCompounding

Up- and Downstream equipment - Feeding

Example: Flexwall with Single-screw or
Twin-screw discharge); Brabender design



also possible:
- K-Tron
- Colortronic
- Schenck



Recycling and EdelweissCompounding

Up- and Downstream equipment - Pelletizing

Example: UWP-system

Gala Automatik design, Pearlo



Example: UWP-system

Econ design, EUP 1500



Agenda



KraussMaffei Group and KraussMaffei Berstorff



KMB Compounding



Recycling and EdelweissCompounding



Conclusion and Challenges

Conclusion and Challenges

Conclusion

- **From waste to value**
 - Focus on high quality Compounding out of plastic waste (Fibres, Film, Re grind)
 - Value adding by Up-Cycling rather than Re-Pelletizing (“Virgin quality Compounds”)
 - Max. reduction of thermal stress
 - Energy and time saving production
 - Highest flexibility in terms of Compounding Applications

- **High capacities**
 - 1st stage: 300 kg/h up to 3.500 kg/h
 - 2nd stage: 500 kg/h up to 6.000 kg/h

- **Proven**
 - in production scale lab tests and sold lines
 - intelligent combination of proven technologies

Conclusion and Challenges

Challenges

- **Know-how / Formulations / Recipe**
 - Protected intellectual property must be supplied by Customer or 3rd party
 - Market Access (Recycler / Compounder)

- **High Outputs:**
 - Bottleneck is continuous filtration (not Twin-screw Extrusion)

- **Smell:**
 - Adding special Additives / Odours
 - Improve pre-washing process
 - Use Active Extruder degassing with Stripping

- **Availability of constant Raw-material**
 - Homogenization by mixing Silos - highest flexibility is needed

Opening of EdelweissCompounding Trial-centre

What

Opening of EdelweissCompounding Trial centre for dedicated customer trials

When

27th / 28th of June

Where

WKR GmbH, Dieselstr. 12, A-4623 Gunskirchen

Thank you!



Carl P. Pöpel

Head of Product Management
Twin-screw Extrusion

KraussMaffei Berstorff GmbH

An der Breiten Wiese 3-5
30625 Hannover

Germany

Phone + 49 (0) 511 5702 518

Ralf.J.Dahl@kraussmaffeiberstorff.com

www.kraussmaffeiberstorff.com