

Inline Melt Characterization of rPellets – Adding value to recycling



Amsterdam, March 30, 2017
Daniel Szymanek, Area Sales Manager, NGR
Gernot Schaffler, Manager New Technologies, Dr. Collin

NEXT GENERATION GROUP



MANUFACTURING

CONSUMPTION

PRODUCT DESIGN

RECYCLING



PRODUCT DESIGN

- > Active support with analytical instruments
- > Optimizing of material + material-converting
- > Development of eco-efficient products

MANUFACTURING

- > Seamless integration of recycling in material-logistics
- > High-grade pellets out of production scrap
- > „Zero Scrap“ in plastic-converting


CONSUMPTION

- > Creating eco-awareness
- > Adaption of consumer-habits
- > Promotion of eco-efficient products

RECYCLING

- > Innovative recycling-solutions for end-of-life plastics
- > Quality-Management of rPellets + high performance filtration
- > Efficient waste-management


PLASTIC STREAM EU28+N/CH



PRE Plast Recyclers Europe, 2015 and Plastics Europe, 2015

FORECAST 2025

- > EU circular economy – new targets 2025
- > Quote plastic packaging increases from 22,5% to 55%
- > Awaiting significant higher trade volume per month – actual approx. 650 000 to per month in EU
- > Dramatic increase of rPellet production
- > The big question – quality
- > The bigger question – price development



WHY QUALITY CONTROL?

- > Recycling becomes more difficult because of more complex use (multilayer film)
- > Automotive industry asks for definition of quality and specifications, traceability
- > Industry is asking for recycling material with specifications close to virgin material


1. WIPAG Gruppe – Carbon-Compounding

| Material | Norm | DIM | WIC PP 10 | WIC PP 15 | WIC PP 20 | WIC PP 30 | WIC PP 40 |
|--------------------------------------------------------|-----------|----------------------|-------------------|-------------------|-------------------|-------------------|------------------|
| Dichte / density | ISO 1183 | [g/cm ³] | 0,95 | 0,97 | 1,01 | 1,05 | 1,11 |
| Schlagzähigkeit (23°C)/ Impact 1eU 4J | ISO 179 | [kJ/m ²] | 30 | 35 | 40 | 48 | 37 |
| Kerbschlagzähigkeit (23°C)/ notched impact 1eA 0,5J/2J | ISO 179 | [kJ/m ²] | 4 | 6 | 7 | 8 | 7 |
| Zug-E-Modul/ Tensil-E-Modulus (ET) 1mm/min 1A | ISO 527/2 | [MPa] | 5.600 | 8.000 | 9.700 | 13.000 | 15.500 |
| Zugfestigkeit (RM)/ tensile strength 5mm/min 1A | ISO 527/2 | [MPa] | 55 | 73 | 79 | 90 | 90 |
| Reißdehnung/ elongation at break (AB) | ISO 527/2 | [%] | 1,8 | 1,8 | 1,6 | 1,3 | 1 |
| Schrumpfung/ shrinkage | | [%] | L:0,18; B:1,44 | L:0,15; B:1,25 | L:0,08; B:1,15 | L:0,05; B:0,91 | L:0,0; B:0,80 |



5. Stoßfänger-Recycling - Materialeigenschaften

PP/EPDM Recompound aus Altstoßfängern



PCR = Post Consumer Recyclate
(Alter der Teile ca. 10 Jahre)

Source: Speech at 19th Internationaler Altkunststofftag, 21.-22.6.2016 in Bad Neuenahr/BRD

- **Conditions**
 - Recycling machines with increasing throughputs
 - need of higher ratio of recycled plastic in products requires preciser property specifications
 - pressure on the market because of prices
- **Needs**
 - minimization of off-spec waste
 - quick and extensive monitoring of material properties
 - intervention in the converting process by off-spec
- **Weakness of laboratory control**
 - too much time flies during material testing in laboratories

Measuring methods with following performances:

- quick response (near to the converting machine)
- adequate sensitivity to identify deviations from specification
- robust test assembly
- constant environment (Temp., moisture, ...)
- statistical significance
- correlation with laboratory test methods
- comparability
- time dependent monitoring
- customizable

A new approach in quality control at the recycling process

Comprehensive Characterisation

- melt and solid state properties
- customizable due to modularity

Interaction

- possibility to influence the converting process by communication to the production line
- specified action limits

Permanent Monitoring

- display chronological sequences
- trace of drifts and deviations
- constancy of measured data precede laboratory values


Marketable

- compact size
- economically priced components

Taking out a side stream of the melt from the production line and cast a film - then various inspection methods can be combined

- melt viscosity (before casting a film)
- optical inspection (gel counting)
- colorimetry
- infrared detection of impurities
- tensile test
- ...


The modularity of the system allows a customized configuration with different measuring systems.



- modular and compact measuring device
- collecting all data in one system
- clearly represented data overview
- detailed information for each setting parameter
- chronological sequence of each measured value
- upper and lower control limits
- data storage
- data transfer to the production I



POLYTEST • LINE



- The system is construed for a **mass flow** rate up to approx. **2.5 kg/h**.
- The **flat film die** has a cross section of **0.5 x 100mm²**.
- **Line Speed** up to **5m/min**.
- Best Performance with film thickness of approx. 50µm and line speed of 2-3m/min.
- calculated apparent viscosity at a rheological slit die
- optical inspection with a **resolution** of approx. **30µm**
- colorimetry at **CIE L*a*b*** color space
- NIR with a multispectral sensor (sensitivity 5-10%)
- measured stress-strain relationship at constant elongation
- **Dimensions:** 1200x580x1690mm
- Data exchange via PROFINET protocol with the production line



Comprehensive inspection device for testing film quality

- **Comfortable.** Quick melt and film inspection at the production line.
- **Compact.** Low space requirements due to the compact design.
- **Output-raising.** Reduction of the quantity of waste in the production process.
- **Modular.** Cost-efficient components.



For more information regarding COLLIN Polytest Line

Dipl.-Ing. Gernot Schaffler
Manager New Technologies



Dr. COLLIN GmbH
Sportparkstrasse 2
D-85560 Ebersberg
Fon: +49 (0) 8092 / 2096-955
Mob: +49 (0) 1525 / 4845681
Email: g.schaffler@drcollin.de
Web: <http://www.drcollin.de>

Thank you!